


OWNER'S INSTRUCTION MANUAL

It is of vital importance, before attempting to operate your engine, to read the general **'SAFETY INSTRUCTIONS AND WARNINGS'** section on pages 2-4 of this booklet and to strictly adhere to the advice contained therein.

- Also, please study the entire contents of this instruction manual, so as to familiarize yourself with the controls and other features of the engine.
- Keep these instructions in a safe place so that you may readily refer to them whenever necessary.
- It is suggested that any instructions supplied with the aircraft, radio control equipment, etc., are accessible for checking at the same time.



CONTENTS

SAFETY INSTRUCTIONS AND WARNINGS ABOUT YOUR O.S. ENGINE -----	2-4	MIXTURE CONTROL VALVE ADJUSTMENT, REALIGNMENT OF MIXTURE CONTROL VALVE, SUBSEQUENT STARTING PROCEDURE -----	14
INTRODUCTION, BASIC ENGINE PARTS -----	5	SUBSEQUENT READJUSTMENT, CARBURETOR CLEANLINESS. ENGINE CARE AND MAINTENANCE -----	15
INSTALLATION -----	6	ENGINE EXPLODED VIEW & PARTS LIST -----	16
THROTTLE LINKAGE, INSTALLATION OF SILENCER (MUFFLER) -----	7	CARBURETOR EXPLODED VIEWS & PARTS LIST -----	17
FUEL TANK LOCATION, GLOWPLUGS -----	8	O.S. GENUINE PARTS & ACCESSORIES -----	18
FUEL, PROPELLER -----	9	THREE VIEW DRAWING -----	19
MIXTURE CONTROLS, STARTING -----	10	MEMO -----	20
RUNNING-IN ("Breaking-in") -----	11-12		
MIXTURE CONTROL ADJUSTMENT CHART -----	13		


SAFETY INSTRUCTIONS AND WARNINGS ABOUT YOUR O.S. ENGINE

Remember that your engine is not a "toy", but a highly efficient internal-combustion machine whose power is capable of harming you, or others, if it is misused or abused. As owner, you, alone, are responsible for the safe operation of your engine, so act with discretion and care at all times.

If at some future date, your O.S. engine is acquired by another person, we would respectfully request that these instructions are also passed on to its new owner.

- The advice which follows is grouped under two headings according to the degree of damage or danger which might arise through misuse or neglect.

 WARNINGS
These cover events which might involve serious (in extreme circumstances, even fatal) injury.

 NOTES
These cover the many other possibilities, generally less obvious sources of danger, but which, under certain circumstances, may also cause damage or injury.

2



WARNINGS

• Never touch, or allow any object to come into contact with, the rotating propeller and do not crouch over the engine when it is running.



• A weakened or loose propeller may disintegrate or be thrown off and, since propeller tip speeds with powerful engines may exceed 600 feet (180 metres) per second, it will be understood that such a failure could result in serious injury, (see 'NOTES' section relating to propeller safety).

• Model engine fuel is poisonous. Do not allow it to come into contact with the eyes or mouth. Always store it in a clearly marked container and out of the reach of children.



• Model engine fuel is also highly flammable. Keep it away from an open flame, excessive heat, sources of sparks, or anything else which might ignite it. Do not smoke or allow anyone else to smoke, near to it.



• Never operate your engine in an enclosed space. Model engines, like automobile engines, exhaust deadly carbon-monoxide. Run your engine only in an open area.

• Model engines generate considerable heat. Do not touch any part of your engine until it has cooled. Contact with the muffler (silencer), cylinder head or exhaust header pipe, in particular, may result in a serious burn.



NOTES

- This engine was designed for model aircraft. Do not attempt to use it for any other purpose.
- Mount the engine in your model securely, following the manufacturers' recommendations, using appropriate screws and locknuts.
- Be sure to use the silencer (muffler) supplied with the engine. Frequent exposure to an open exhaust may eventually impair your hearing. Such noise is also likely to cause annoyance to others over a wide area.
- Install a top-quality propeller of the diameter and pitch specified for the engine and aircraft. Locate the propeller on the shaft so that the curved face of the blades faces forward-i.e. in the direction of flight. Firmly tighten the propeller nut, using the correct size wrench.
- Always check the tightness of the propeller nut and retighten it, if necessary, before restarting the engine, particularly in the case of four-stroke-cycle engines. A safety locknut assembly is provided. Always use it. This will prevent the propeller from flying off in the event of a "backfire", even if it loosens.
- If you install a spinner, make sure that it is a precision made product and that the slots for the propeller blades do not cut into the blade roots and weaken them.
- Discard any propeller which has become split, cracked, nicked or otherwise rendered unsafe. Never attempt to repair such a propeller: destroy it. Do not modify a propeller in any way, unless you are highly experienced in tuning propellers for specialized competition work such as pylon-racing.
- Use an electric starter for this engine. The wearing of safety glasses is also strongly recommended.

! NOTES

- Take care that the glow plug clip or battery leads do not come into contact with the propeller. Also check the linkage to the throttle arm. A disconnected linkage could also foul the propeller.
- After starting the engine, carry out any needle-valve readjustments from a safe position behind the rotating propeller. Stop the engine before attempting to make other adjustments to the carburettor.
- Adjust the throttle linkage so that the engine stops when the throttle stick and trim lever on the transmitter are fully retarded. Alternatively, the engine may be stopped by cutting off the fuel supply. Never try to stop the engine physically.
- Take care that loose clothing (ties, shirt sleeves, scarves, etc.) do not come into contact with the propeller. Do not carry loose objects (such as pencils, screwdrivers, etc.) in a shirt pocket from where they could fall through the propeller arc.
- Do not start your engine in an area containing loose gravel or sand. The propeller may throw such material in your face and eyes and cause injury.
- For their safety, keep all onlookers (especially small children) well back (at least 20 feet or 6 meters) when preparing your model for flight. If you have to carry the model to the take-off point with the engine running, be especially cautious. Keep the propeller pointed away from you and walk well clear of spectators.
- Warning! Immediately after a glowplug-ignition engine has been run and is still warm, conditions sometimes exist whereby it is just possible for the engine to abruptly restart if the propeller is casually flipped over compression WITHOUT the glowplug battery being reconnected. Remember this if you wish to avoid the risk of a painfully rapped knuckle!


4

INTRODUCTION

This 'RN' version of the MAX-BGX-1 RING is fitted, as standard, with a 'remote' needle-valve, mounted at the back of the engine, safely distanced from the propeller. This device was originated by OS several years before being adopted by a number of other manufacturers.

INSTALLING THE GLOW PLUG


Carefully insert plug, with washer, fingertight only, before final tightening with the correct size plug wrench.



BEFORE INSTALLING THE REMOTE NEEDLE

- Fit the remote needle to the attachment bracket as shown in the photo.
- When beam-mounting the engine in the model, bolt the engine to the bearers along with the attachment bracket. Please refer to the INSTALLATION section of the engine instructions when installing the engine.
- Connect the needle-valve to carburettor jet nozzle with silicone tubing supplied. In the event of the tubing becoming damaged, it should be replaced with 78mm length of 5mm ODX2mm ID silicone tubing.

BASIC ENGINE PARTS



5

INSTALLATION

There are two methods of installing the engine in the aircraft: (a) standard beam mounting, using the engine's integral crankcase mounting lugs, and (b) radial mounting, using the backplate mount supplied, to bolt the engine to the front bulkhead or firewall. Whichever method is chosen, make sure that the structure to which the engine is attached (i.e. horizontal bearers or vertical bulkhead), is of sturdy proportions and very firmly integrated with the airframe. This is necessary both for safety and for the realisation of maximum performance.


Beam mounting

- Use heavy, rigid, hardwood bearers or a metal mount and keep unsupported length as short as possible to reduce frontal overhang.
- Make sure that the bearers are parallel and that their mounting surfaces are in the same plane.
- Use 5mm or 10-24 steel cap-head screws, such as Allen hexagon socket type, with locknuts, for bolting the engine to the bearers.

Radial mounting

- Draw vertical and horizontal centre lines on the firewall to correspond with the required thrust-line. Use these to find the centre of the 100mm (3.93 in.) diameter bolt-circle required to correctly locate the backplate mount.

- Depending on whether the engine is to be installed with the cylinder upright, inverted, angled or horizontal, position the backplate mount so that the access hole in the side of the mount is conveniently located to receive the fuel line and muffler-pressure line from tank to engine. Place the mount against the firewall so that its six mounting holes are accurately aligned on the bolt circle. Mark off the bolt-hole centers and drill six 6.5mm holes through the firewall.
- Remove the crankcase cover plate from the engine. Carefully slide the O-ring seal from the cover plate and fit it, to the retaining groove on the backplate mount.
- Fit the backplate mount to the engine in the required position and secure it firmly with the four M5x22 Allen screws provided.
- Bolt the complete engine and backplate mount assembly to the firewall, using the six M5x25 Allen screws, toothed lock washers and blind nuts supplied.



6

THROTTLE LINKAGE

- Before connecting the throttle-lever/servo linkage, make sure that no part of the linkage interferes with the internal structure of the aircraft or wiring, etc., when the throttle is fully open or fully closed.
- Set the throttle lever linkage so that the throttle rotor is (a) fully open when the transmitter throttle stick is fully advanced and (b) fully closed when the throttle stick is fully retarded. Adjustment of the throttle rotor opening at the idling position can then be made with the throttle trim lever on the transmitter. (Select throttle-lever and servo-horn hole positions that will avoid excessive pushrod travel causing the throttle to bind at either end.)

Note:

When adjusting the throttle lever angle, relative to the rotor, hold the rotor at about half-way between the open and closed positions while loosening and tightening the fixing screw, otherwise the rotor, rotor guide screw, throttle stop screw or carburetor body may become burred and damaged.

INSTALLATION OF SILENCER(MUFFLER)

To fit the standard silencer


1. Fix the exhaust adaptor plate to the engine with the two M5 x15 Allen screws supplied.
2. Now fit the silencer to the exhaust adaptor with M5x20 Allen screws, also provided.

NOTE:

In order to prevent the leakage of exhaust oil from between the engine and adaptor, and between the adaptor and silencer, apply a suitable silicone sealant to the joint faces during assembly.

The angled exhaust outlet is adjustable and can be rotated to any desired position in the following manner.

1. Loosen locknut and assembly screw.
2. Set the exhaust outlet at the required angle by rotating the rear part of the silencer.
3. Re-tighten the assembly screw, followed by the locknut.




7

FUEL TANK LOCATION

A 700cc or 24 oz. fuel tank gives approximately 10 minutes running time, with variations according to throttle setting, propeller size and fuel used. Use muffler pressurization and locate the tank so that its centre line is 10-15mm below the level of the needle-valve. Also, position the tank as close to the engine as possible, i.e. immediately behind the firewall.

Note: If the model is left unattended with the fuel tank filled, fuel may flow into the carburetor, causing it to "flood" the engine and making it difficult to start. Take appropriate action to prevent this, e.g. shut off the needle-valve or pinch the fuel delivery tube with a suitable clip.



GLOWPLUGS

Since the compatibility of glowplug and fuel may have a marked effect on performance and reliability, it would be worthwhile to try different heat range glowplugs. Recommended O.S. plugs are Nos. 8 and A5. Carefully install the plug finger-tight, before final tightening with the correct size plug wrench.

The role of the glowplug

With a glowplug engine, ignition is initiated by the application of a 1.5-volt power source. When the battery is disconnected, the heat retained within the combustion chamber remains sufficient to keep the plug filament glowing, thereby continuing to keep the engine running. Ignition timing is 'automatic' : under reduced load, allowing higher rpm, the plug becomes hotter and, appropriately, fires the fuel/air charge earlier; conversely, at reduced rpm, the plug become cooler and ignition is retarded.

Glowplug life

Particularly in the case of very high performance engines, glowplugs must be regarded as expendable items.

However, plug life can be extended and engine performance maintained by careful use, i.e.:

- Fit a plug suitable for the engine.
- Use fuel containing a moderate percentage of nitromethane unless more is essential for racing events.
- Do not run the engine too lean and do not leave the battery connected while adjusting the needle.

When to replace the glowplug

Apart from when actually burned out, a plug may need to be replaced because it no longer delivers its best performance, such as when:

- Filament surface has roughened and turned white.
- Filament coil has become distorted.
- Foreign matter has adhered to filament or plug body has corroded.
- Engine tends to cut out when idling.
- Starting qualities deteriorate.

8

FUEL

Select, by practical tests, the most suitable fuel from among the best quality fuels available in your country for model use. For the best performance, a fuel containing 5% to 20% nitromethane is preferable. Lubricants may be either castor-oil or a suitable synthetic oil (or a blend of both) provided that they are always of top quality.

For consistent performance and long engine life, it is essential to use fuel containing AT LEAST 18% lubricant by volume. Some fuels containing coloring additives tend to deteriorate and may adversely affect running qualities.

Once a satisfactory fuel has been selected and used for a while, it may be unwise to needlessly change the brand or type. In any engine, a change of fuel may cause carbon deposits in the combustion chamber or on the piston head to become detached and lodged elsewhere, with the risk of this causing unreliable operation for a while. If, however, the adoption of a different fuel is unavoidable, check the engine for the first few flights on the new fuel, by temporarily reverting to the running-in procedure.



Model engine fuel is poisonous. Do not allow it to come into contact with the eyes or mouth. Always store it in a clearly marked container and out of the reach of children.



Model engine fuel is also highly flammable. Keep it away from open flame, excessive heat, sources of sparks, or anything else which might ignite it. Do not smoke, or allow anyone else to smoke, near to it.

PROPELLER

The suitability of the prop depends on the size and weight of the model and type of flying. Determine the best size and type after the engine has been run in. Check the balance of the propeller before installing on the engine. Unbalanced propellers cause vibration and loss of power. Wooden propellers are to be preferred. Some nylon propellers are not strong enough to withstand the high power output of these engines and a thrown blade can be very dangerous.

Sports & Scale	18x10-12, 20x8-10
----------------	-------------------




Never touch, or allow any object to come into contact with, the rotating propeller and do not crouch over the engine when it is running.

PROPELLER & SPINNER ATTACHMENT

Obviously, this can be very hazardous. To eliminate such dangers, the O.S. Safety Locknut Assembly was devised.

Install this as follows:

1. Ream the propeller shaft hole to 9.6mm bore with an appropriate reamer, checking that the hole is exactly centered.
2. Install the prop to the engine shaft, followed by the retaining washer and prop nut and tighten firmly with a 17mm wrench.
3. Add the special tapered and slotted locknut and secure with a 14mm wrench while holding the prop nut with the 17mm wrench.



9

MIXTURE CONTROLS

Two mixture controls are provided on these engines.

•The Needle Valve


When set to produce maximum power at full throttle, this establishes the basic fuel/air mixture strength. The correct mixture is then maintained by the carburetor's built-in automatic mixture control system to cover the engine's requirements at reduced throttle settings.

•The Mixture Control Valve (carburetor)

This meters fuel flow at part-throttle and idling speeds to ensure reliable operation as the throttle is opened and closed. The Mixture Control Valve is factory set for the approximate best result. First run the engine as received and readjust the Mixture Control Screw only if necessary.

STARTING

1. Fill the fuel tank. Do not allow fuel to overflow into the silencer, otherwise the engine may become flooded and difficult to start.
2. Check that the needle-valve is closed. (Do not overtighten.) Now open the needle-valve 1-1.5 turns (when the standard E-5010 silencer is used) or 1.5-2 turns (when a tuned silencer is used), from the fully closed position.



10


RUNNING-IN ("Breaking-in")

All internal-combustion engines benefit from extra care when they are run for the first few times-known as running-in or breaking-in. This is because the working parts of a new engine take some time to settle down after being subjected to high temperatures and stresses. Therefore, it is vitally important to complete the break-in before allowing the engine to run continuously at high speed and before finalizing carburetor adjustments. However, because O.S. engines are produced with the aid of the finest modern precision machinery and from the best and most suitable materials, only a short and simple running-in procedure is called for and can be carried out with the engine installed in the model.

The process is as follows.

1. Install the proper propeller intended for your model. Open the needle-valve and start the engine. Run the engine for two to three minutes with the throttle fully open, but with the needle-valve adjusted for rich, slow "four-cycle"operation.
2. Now close the needle-valve until the engine speeds up to "two-cycle"operation and allow it to run for about 10 seconds, then reopen the needle-valve to bring the engine back to "four-cycle"operation and run it for another 10 seconds. Repeat this procedure until the fuel tank is empty.
3. Refer to IDLING ADJUSTMENT section and fix the idling position where the lowest possible r.p.m., with steady running, is obtained.
4. Re-start and adjust the needle-valve so that the engine just breaks into "two-cycle" from "four-cycle" operation, then make three or four flights, avoiding successive "nose-up" flights.

5. Set the throttle rotor slightly open (2-3mm) from the closed position. (This is to avoid unnecessarily high r.p.m. when the engine starts.)
6. Connect battery leads to glowplug.



7. Bring electric starter into contact with spinner and depress starter switch for one or two seconds. Repeat if necessary. When the engine starts, withdraw the starter immediately.

Attention :

Do not choke the carburetor air intake when applying the starter. This could cause an excessive amount of fuel to be drawn into the cylinder which may initiate an hydraulic lock and damage the engine.

If the engine does not start within 10 repeat applications of the starter, remove the glow-plug, check that it glows brightly and that the cylinder is not flooded with fuel. (To eject excess fuel, close needle-valve and apply starter with glowplug removed.) Then try again.

8. When the engine starts, advance the throttle stick slowly checking the increase of r.p.m. Abrupt throttle operation right after starting may cause the engine to stumble or stop.

VERY IMPORTANT!

Before being operated at full power (i.e. at full-throttle and with the needle-valve closed to its optimum setting) the engine must be adequately run-in, otherwise there is a danger of it becoming overheated and damaged. (See RUNNING-IN ["Breaking-in"] .)

5. During subsequent flights, the needle-valve can be gradually closed to give more power.

However, if the engine shows signs of running too lean, the next flight should be set richer. After a total of ten to fifteen flights, the engine should run continuously, at its optimum needle-valve setting, without loss of power.

◆ Optimum Needle setting (1)

Slowly advance the throttle to its fully open position, then gradually close the needle-valve until the exhaust note begins to change.


At this point, disconnect the battery from the glowplug, taking care that the battery leads or glowplug clip do not come into contact with the rotating propeller. If the engine stops when the battery is disconnected, close the needle-valve about 30° and restart.

◆ Optimum Needle setting (2)

As the needle-valve is closed slowly and gradually, the revolutions of the engine will be increased and a continuous high-pitched exhaust note, only, will be heard. Close the needle-valve 10-15° and wait for the change of r.p.m.

After the revolutions of the engine are increased, turn the needle-valve another 10-15° and wait for the next change of r.p.m. As the speed of the engine does not instantly change with needle-valve readjustment, small movements, with pauses between, are necessary to arrive at the optimum setting.

◆ Needle-valve adjustment diagram




Note : This diagram is for reference purposes only. Actual needle positions may differ from those shown.

- To stop the engine, close the throttle completely to cut off fuel/air supply.

12

MIXTURE CONTROL ADJUSTMENT CHART



13

MIXTURE CONTROL VALVE ADJUSTMENT

With the engine running, close the throttle and allow it to idle for about five seconds, then open the throttle fully. If, at this point, the engine is slow to pick up and produces an excess of exhaust smoke, the mixture is too rich. Correct this condition by turning the Mixture Control Screw clockwise 15-30°. If the mixture is excessively rich, engine rpm will become unstable: opening the throttle will produce a great deal of smoke and rpm may drop suddenly or the engine may stop. This condition may also be initiated by excessively prolonged idling.

If, on the other hand, the mixture is too lean, this will be indicated by a marked lack of exhaust smoke and a tendency for the engine to cut out when the throttle is opened. In this case, turn the Mixture Control Screw counter-clockwise 90° to positively enrich the idle mixture, then turn the screw clockwise gradually until the engine regains full power cleanly when the throttle is reopened.

Carry out adjustments patiently until the engine responds quickly and positively to the throttle control.

Note: Mixture Control Valve adjustments should be made in steps of 15-30° initially, carefully checking the effect, on throttle response, of each small adjustment.

REALIGNMENT OF MIXTURE CONTROL VALVE

In the course of making carburetor adjustments, it is just possible that the Mixture Control Valve may be inadvertently screwed in or out too far and thereby moved beyond its effective adjustment range.

Its basic setting can be re-established as follows:

Close the throttle rotor gradually from the fully opened position until it is just fully closed. (Do not turn further.) Then, screw in the Mixture Control Screw until it stops. Now unscrew the Mixture Control Screw approx. 2 ½ turns.

SUBSEQUENT STARTING PROCEDURE

Once the optimum needle-valve setting has been established (see page 12, Needle-valve adjustment diagram) the procedure for starting may be simplified as follows.

1. Open the needle-valve one half-turn (180°) from the optimum setting.
2. Set the throttle rotor slightly open from the fully closed position, energize the glowplug and apply the electric starter. When the engine starts, re-open the throttle and re-adjust the needle-valve to the optimum setting.

Note:

When re-starting the engine on the same day, provided that atmospheric conditions have not changed significantly, it may be practicable to re-start the engine on its optimum(running) setting.

14

SUBSEQUENT READJUSTMENT

Once the engine has been run-in and the controls properly set up, it should be unnecessary to alter the mixture settings; except to make minor adjustments to the Needle-Valve occasionally, to take account of variations in climatic conditions. The use of a different fuel, however, particularly one containing more, or less, nitromethane and/or a different type or proportion of lubricating oil, is likely to call for some readjustment of the Needle-Valve. Remember that, as a safety measure, it is advisable to increase the Needle-Valve opening by an extra half-turn counter-clockwise, prior to establishing a new setting. The same applies if the silencer type is changed. A different silencer may alter the exhaust pressure applied to the fuel feed and call for a revised Needle-Valve setting. The use of a different glowplug may also require compensating carburetor readjustments.

CARBURETOR CLEANLINESS

The correct functioning of the carburetor depends on its small fuel orifices remaining clear. The minute particles of foreign matter that are present in any fuel, can easily partially obstruct these orifices and upset mixture strength so that engine performance becomes erratic and unreliable.

O.S.'Super-Filters' (large and small) are available, as optional extras, to deal with this problem. One of these filters, fitted to the outlet tube inside your refueling container, will prevent the entry of foreign material into the fuel tank.

It is also recommended that a good in-line filter be installed between the tank and needle-valve. Do not forget to clean the filters regularly to remove dirt and lint that accumulate on the filter screen. Also, clean the carburetor itself occasionally.

ENGINE CARE AND MAINTENANCE

1. At the end of each operating session, drain out any fuel that may remain in the fuel tank.
2. Next, energize the glowplug and try to restart the engine to burn off any fuel that may remain inside the engine. Repeat this procedure until the engine fails to fire. Remove the glowplug and eject any residue by rotating the engine with an electric starter for 4 to 5 seconds while the engine is still warm.
3. Finally, inject some corrosion inhibiting after-run oil into the engine. Rotate the engine a few times by hand, to make sure that it is free, and then with an electric starter for 4 to 5 seconds to distribute the oil to all the working parts.


Note:

Do not inject corrosion inhibiting after-run oil into the carburetor as this may cause the O-ring inside the carburetor to deteriorate.

These procedures will reduce the risk of starting difficulties and of internal corrosion after a period of storage.

15

ENGINE EXPLODED VIEW



* Type of screw


C...Cap Screw M...Oval Fillister-Head Screw
F...Flat Head Screw N...Round Head Screw S...Set Screw

No.	Code No.	Description
1	29304000	Cylinder Head
2	29303100	Cylinder Liner
3	29303400	Piston Ring
4	29303200	Piston
5	29306000	Piston Pin
6	29317000	Piston Pin Retainer (2pcs.)
7	29305000	Connecting Rod
8	29383010	Carburetor Complete (Type 8AA-RN)
9	29310100	Propeller Lock Nut Set
10	29308000	Drive Hub
10-1	29208200	Woodruff Key
11	29320000	Thrust Washer
12	46231000	Crankshaft Ball Bearing (Front)
13	29301000	Crankcase
14	71704230	Remote Needle Valve Bracket (BGX-1)
15	28282000	Remote Needle Valve Assembly
15-1	28281970	Needle
15-2	24981837	"O" Ring
15-3	26381501	Set-Screw
15-4	26711305	Ratchet Spring
15-5	46181950	Fuel Outlet
16	29330000	Crankshaft Ball Bearing (Rear)
17	29302000	Crankshaft
18	29314010	Gasket Set
19	29307000	Cover Plate
20	29313000	Screw Set
	71919000	Backplate Mount
	71608001	Glowplug No.8
	29325000	E-5010 Silencer
	29325300	Assembly Screw
	29325400	Retaining Screw (C.M5x20 2pcs.)
	29326000	Exhaust Adaptor

The specifications are subject to alteration for improvement without notice.

16

CARBURETOR EXPLODED VIEW & PARTS LIST



* Type of screw

C...Cap Screw M...Oval Fillister-Head Screw
F...Flat Head Screw N...Round Head Screw S...Set Screw

No.	Code No.	Description
1	29381100	Carburetor Body
2	22881300	Plug Screw
3	22681953	Fuel Inlet
4	28281600	Rotor Guide Screw
5	28281500	Rotor Spring
6	28281200	Carburetor Rotor
7	28281210	Carburetor Insert
8	29381300	Mixture Control Screw Assembly
8-1	27881820	"O" Ring (2pcs.)
9	28281400	Throttle Lever Assembly
10	24925202	Carburetor Retaining Screw
11	29315000	Carburetor Rubber Gasket

The specifications are subject to alteration for improvement without notice.

17

O.S. GENUINE PARTS & ACCESSORIES

■ GLOWPLUG

No.8 (71608001)



A5 (71605100)



■ BOOSTER TERMINAL KIT

(72200130)



■ NEEDLE VALVE EXTENSION CABLE SET

(72200080)



■ SILICONE TUBE ASSEMBLY

(72102300)



■ EXHAUST HEADER PIPE

(72102200)



■ T-6000 TUNED SILENCER

(72102010)



■ PROPELLER LOCKNUT SET FOR SPINNER

3/8"-M5(S) (29310110)



■ NON-BUBBLE WEIGHT

(71531000)




■ CAP SCREW SET (10pcs.)

M3.5x12 (79871080)



■ LONG SOCKET WRENCH WITH PLUG GRIP

(71521000)



■ SUPER FILTER (L)

(72403050)



■ BLIND NUTS (10pcs.)

M4 (79870040)

M5 (79870050)



■ LOCK WASHER (10sets)

M4 (55500003)

M5 (55500004)






The specifications are subject to alteration for improvement without notice.

18

THREE VIEW DRAWING

Specifications

■ Displacement	34.97 cc / 2.13 cu.in.
■ Bore	37.3 mm / 1.469 in.
■ Stroke	32.0 mm / 1.260 in.
■ Practical R.P.M.	1.500-10.000r.p.m.
■ Output	4.1 ps / 4.16 hp / 10.000r.p.m.
■ Weight	1,340 g / 47.30 oz.



Dimensions(mm)

19

MEMO

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....



O.S. ENGINES MFG.CO.,LTD.

6-15 3-Chome Imagawa Higashisumiyoshi-ku
Osaka 546-0003, Japan TEL. (06) 6702-0225
FAX. (06) 6704-2722

URL : <http://www.os-engines.co.jp>